


Printing a Nozzle Check

To begin a nozzle check on the flat bed, pick your material and size (big enough for the test size 1100x110mm).

Choose nozzle test on the top right of the screen.

Choose the flatbed option on job parameters 'type' so it looks like below.



Once your material is secure on the bed, hit print and start.

Revision #1

Created 3 October 2022 14:04:15 by Matt Parris

Updated 3 October 2022 14:14:26 by Matt Parris