

# Interlinked Smoke Detectors/Alarms

There are x10 X-Sense Interlinked smoke detectors. (XS01-WR).

## To Test the Alarms

### **Individual Alarms**

To test an individual alarm **press once** the button on the side of the unit.

### **All Interlinked Alarms**

To test the full interlinked system - **press and hold** the button until all other alarm sounders are activated.

Copy of the instructions: Z:\Staff Folder\MANUALS & TRAINING\Fire Alarms

[X-Sense Interlinked Smoke Alarms.pdf](#)

---

Revision #1

Created 6 November 2023 12:20:55 by Richard McCombe

Updated 6 November 2023 12:41:29 by Richard McCombe