

# Zund Cut Server - Unable to Communicate with Zund Cut Server

If you see the below error. Turn off Zund Cut Server Direct in Cutter Settings

[image1696587973079.png](#)

[image1696588018593.png](#)

[image1696588039547.png](#)

[image1696588074224.png](#)

[image1696588129041.png](#)

---

Revision #1

Created 6 October 2023 10:25:13 by Printing Account

Updated 6 October 2023 10:28:56 by Printing Account