



Maintenance

Maintenance on the Fixation unit should be done **Weekly**.

Fixation Unit Maintenance Procedure




1. The Fixation Unit should be completely cold
2. Open the two latches at the front of the Fixation Unit




Latches

3. Using 2 people open the fixation unit, THE DOOR IS VERY HEAVY



4. Using the chain links on the left and the right hook the door to the top of the Fixation Unit



5.




on C



or

1. Located on the left and right hand side of the machine



2. Spray from the top to the bottom to allow for even coating

6. Lower the door back in place **THE DOOR IS VERY HEAVY, THIS IS A TWO PERSON OPERATION**

Revision #2

Created 6 May 2022 07:48:49 by Admin

Updated 11 May 2022 10:04:15 by Admin