

Troubleshooting

- Zund Camera is not switching on

Zund Camera is not switching on

Reboot the system.