

# Troubleshooting

- [Zund Camera is not switching on](#)

# Zund Camera is not switching on

Reboot the system.